

Push Fit Glove System user Instructions

The Lakeland ChemMAX® “Push-Fit” glove system is a simple method of attaching most types of chemical gloves to the garment sleeve through the use of two concentric rings.

The system has been fully tested to Type 3* and is certified with the garment (ChemMAX 1, 2, or 3) Garments can be supplied with gloves attached or the ring system can be purchased separately so that customers may attach their own choice of glove

Fitting Instructions

1
Pull the cuff of the glove over the white ring - insert the narrower end of the ring first
Pull the cuff over the full length of the ring



3
Holding the sleeve behind the inner ring slide the black ring over the glove and on to the garment sleeve
Push tightly over the inner ring and ensure the sleeve hem remains hooked over the lip of the inner ring



2
Push the glove with ring into the garmentsleeve
Ensure the correct glove is used for each sleeve and that the palm of the glove



4
Ensure both rings are attached securely and correctly to each sleeve



Contents of Box:

5 sets of Push-Fit Glove Rings (10 White, 10 Black)
User Instruction sheet
ChemMAX 1 Coverall and Gloves
NOT Included

Care Of Products:

1. Ensure product is not damaged before use - always carry out a physical check before using the product(s)
2. These products may be suitable for re-use providing that suitable de-contamination procedures are adhered to and that there is no physical damage to any piece of the system
3. These products should not be repaired if damaged, please dispose of according to local requirements. Store in normal conditions: keep cool and dry and away from direct sunlight
4. Not suitable for use in extremely low temperatures (sub-zero) or temperatures higher than 100oC
5. Keep away from naked flames and high heat sources
6. Selection of the appropriate product for protection is the users responsibility